


Harness Components Location

WIRING SYSTEM

57. Harness Components Location

A: LOCATION



WI-16110

(1) Front wiring harness	(5) Front door cord RH	(9) Rear gate cord
(2) Engine wiring harness	(6) Rear door cord RH	(10) Rear door cord LH
(3) Bulkhead wiring harness	(7) Rear wiring harness	(11) Front door cord LH
(4) Instrument panel wiring harness	(8) Roof cord	(12) Transmission cord